

INSTALLATION INSTRUCTION. Please read this leaflet thoroughly **BEFORE** installation.


CHECK ALL PANELS FOR BATCH, SHADING OR ANY DEFECTS PRIOR TO INSTALLATION

200mm & 250mm PVC

CEILING **panels**

FOR CEILING & WALLS

DECORATIVE PVC CEILING & WALL PANELS



■ 5mm x 250mm x 2700mm or 4000mm*
(4 panels per pack; 2.70sqm or 4.00sqm)
*4.0m only certain decors

■ 6mm x 200mm x 2700mm or 4000mm*
(5 panels per pack; 2.70sqm or 4.00sqm)
*4.0m only certain decors

1. Internal
2. Scotia
3. External
4. L-shape
5. End U
6. H Join

TO CHECK


Before and during installation for visible defects. As is general practice installed panels and extrusions are assumed to be accepted.

FIXING OF PANELS

Decorative pvc panels can be fixed with:

- STAPLES
- PANEL PINS
- SCREWS
- PANEL ADHESIVE

PASS TO END USER



"Grout is Out!"™ "Easy to Fit!"™

PVC PANEL MAINTENANCE

DO NOT EXPOSE TO DIRECT SUNLIGHT, OR TEMPERATURES IN EXCESS OF 60C.

The hardwearing surface of the panelling can be hygienically cleaned with shower-panel Spray Cleaner which is a mild non-abrasive cleaner with an anti-bacterial agent. **Abrasive cleaners and bleaches must NOT be used on PVC panels.**

When fitting lighting if in doubt consult the lighting manufacturer.

Class 1 Fire rated. SUITABLE FOR COMMERCIAL AND DOMESTIC USE.

CHECK ALL PANELS FOR BATCH, SHADING OR ANY DEFECTS PRIOR TO INSTALLATION

200mm & 250mm PVC

CEILING panels

FOR CEILINGS & WALLS

DECORATIVE PVC CEILING & WALL PANELS



INSTALLATION INSTRUCTION. Please read this leaflet thoroughly **BEFORE** installation.

PVC PANEL MAINTENANCE


Decorative PVC panels can be fixed directly to the wall if the surface is relatively even and if the wall is dry, using shower panel adhesive, or fix on to a frame of wooden battens.

When fitting decorative PVC panels to the ceiling, always fix to a frame of wooden battens.

When fixing decorative PVC panels to wooden battens, the panels can be fixed through the extending backplate fixing tongue using staples with a staple gun, by hammer with panel pins/nails, with screws, or with panel adhesive. When fixing to the ceiling, adhesive should only be used with additional fixing combined with staples, panel pins/nails, or screws.


- To make a wooden frame, strap the wall with wooden battens placed approximately every 30-40 cm according to the direction of assembly. If panels are assembled vertically, strap in the opposite direction horizontally, and vice-versa. If panels are assembled diagonally, the battens can be installed vertically, horizontally, or at right angles to the panels.
- Start with the preferred end moulding - end "U", internal, external, or scotia. Insert the tongue side of the panel into the moulding.
- Glue the panel, or panel-pin (nail), staple or screw the first panel through the backplate fixing tongue opposite the starting side.
- Insert the tongue of the next panel into the groove and continue the installation of the panels in the same manner.
- Use appropriate PVC mouldings to finish all corners and ends.
- DECORATIVE CLIP-IN SILVER MOULDINGS: If a decorative clip-in silver moulding is to be used, clip this into the groove before inserting the second and subsequent panels, then glue the panel, or panel-pin (nail), staple or screw through the panel backplate fixing tongue.
- DECORATIVE H-JOIN MOULDINGS: If a decorative H-join moulding is used, insert the H-join before fixing the backplate of the first panel and before inserting the second and subsequent panels, then glue the first panel and H-join, or panel-pin (nail), staple or screw through the H-join backplate fixing tongue to fix both the H-join and the first panel. Before inserting an H-join, the panel tongues should first be trimmed off both sides of the panels.
- SEALING: Seal the panels with decorative PVC panel silicone sealant between panel joins and mouldings/profiles and all ends if the panels are to be installed in a wet area such as in a shower or around a bath - clean excess sealant with a clean damp cloth immediately.

PANEL PREPARATION



CUTTING PANELS:

Using a handsaw cut panels with decorative face upwards. When using an electric saw cut panels with decorative face downwards.



PIPES AND ACCESSORIES:


Leave a 3-4mm clearance around all pipes and accessories and seal with a bead of shower-panel sealant. If a collar is to be fitted, first seal with shower-panel sealant.

TO CHECK

Before and during installation for visible defects. As is general practice installed panels and extrusions are assumed to be accepted.


THE SIDES OF PANELS SHOULD BE TRIMMED TO FORM A TIGHT FIT

TONGUE & GROOVE PANEL INSTALLATION



shower-panel adhesive. Seal all panel joins and extrusions using shower-panel sealant.

WHERE TO START - Start at the corner furthest from the door, panel in both directions around the room. The last panel is fitted above the doorway, placed in position. All panels must be correctly aligned and plumb, allowing for 3mm expansion in corners within the extrusions. Fix panels to battens using shower-panel adhesive. Seal all panel joins and extrusions using shower-panel sealant.



FIRST FIT THE BASE SEAL EXTRUSIONS

battens with shower-panel adhesive, and sealing extrusions with shower-panel sealant. Allow for 3-4mm expansion gaps, filled with shower-panel sealant.

BEGIN PANELLING - Fix an internal corner profile in position ensuring that it is plumb. Apply shower-panel sealant to the recess of the profile. Apply shower-panel adhesive to the battens. Insert the first panel after cutting to size. Then continue to panel away from the corner in both directions, fixing panels to



RECOMMENDED FOR ALL INSTALLATIONS

CONTINUE PANELLING - Continue panelling around the room fixing each panel to the battens with shower-panel adhesive. Seal all joins using shower-panel sealant. Use internal and external corner profiles, sealing with shower-panel sealant, where appropriate.

Retro-fit L-shape & Scotia extrusions can be used.

"Grout is Out!"TM

"Easy to Fit!"TM